

Fermentor™ G4 - Carb Stone

Assembly, Operation, & Maintenance



Congratulations on your purchase and thank you for selecting the Carb Stone from Blichmann Engineering™. We are confident that it will provide you years of service and many gallons of outstanding beer. This manual will familiarize you with the use, assembly, and the sanitation procedures for the product.



IMPORTANT INFORMATION

PLEASE READ AND THOROUGHLY UNDERSTAND THIS MANUAL PRIOR TO USE FOR IMPORTANT SAFETY INFORMATION!

- WARNING:** Sections labeled “Warning” can lead to serious injury or death if not followed. Please thoroughly read these sections and understand them completely before use. If you do not understand them or have any questions, contact your retailer or Blichmann Engineering (www.BlichmannEngineering.com) before use.
- CAUTION:** Sections labeled “Caution” can lead to equipment damage or unsatisfactory performance of the equipment. Please read these sections thoroughly. If you have any questions, contact your retailer or Blichmann Engineering (www.BlichmannEngineering.com) before use.
- IMPORTANT:** Sections labeled “Important” should specifically be followed to ensure satisfactory results with the product.

What’s In the Box?

Item Number	Description	Quantity
BE-001764-01	G4 TC Carb Stone - Keg Post	1
BE-000804-00	Gas Ball Lock Post	1
BE-001368-01	O-Ring M2x9 Silicone 70A	1

CLEANING, PREPARATION, and OPERATION

Clean the all the parts with a mild detergent or Powdered Brewery Wash and soak in sanitizer before assembly. Gas post can be threaded onto the post adapter by hand. A wrench is not required.

Install into the port with a clamp and gasket. Ensure that the stone is submerged with beer.

Apply CO2 gas to the stone at the desired pressure. A gas ball-lock is required to connect to the stone.

The stone can be sanitized with common brewing sanitizers or boiled if desired.

OXYGENATION

The CarbStone can be used as an oxygenation stone as well. Using the Blichmann Oxygen Flow Regulator, reference the flow chart below to achieve 8-10 PPM of dissolved oxygen in your wort. This will provide good yeast cell growth and health. It is highly recommended that you use a dissolved oxygen meter to confirm your oxygen levels.

Batch Size*	Duration (min)	
	Regulator Setting (L/min)	
	1 LPM	2 LPM
2.5gal	01:00	00:45
5gal	01:30	01:15
10gal	02:00	01:45
15gal	02:45	02:15
20gal	03:30	03:00
1BBL	04:15	03:45

*Assumes wort volume is within 10-15% of batch size.

These recommendations are guidelines only, as your results may be different.

PSI (Pounds Per Square Inch)

	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24	25	26	27	28	29	30
30°F	1.82	1.92	2.03	2.14	2.23	2.36	2.48	2.60	2.70	2.82	2.93	3.02	3.13	3.24	3.35	3.46	3.57	3.67	3.78	3.89	4.00	4.11	4.22	4.33	4.44	4.66	4.77	4.87	4.98	4.98
31°F	1.78	1.88	2.00	2.10	2.20	2.31	2.42	2.54	2.65	2.76	2.86	2.96	3.07	3.17	3.28	3.39	3.50	3.60	3.71	3.82	3.93	4.03	4.14	4.25	4.35	4.46	4.57	4.68	4.78	4.89
32°F	1.75	1.85	1.95	2.05	2.15	2.27	2.38	2.48	2.59	2.70	2.80	2.90	3.00	3.11	3.21	3.31	3.42	3.52	3.63	3.73	3.84	3.94	4.04	4.15	4.25	4.36	4.46	4.57	4.67	4.77
33°F	1.71	1.81	1.91	2.01	2.10	2.23	2.33	2.43	2.53	2.63	2.74	2.84	2.96	3.06	3.15	3.25	3.35	3.46	3.56	3.66	3.76	3.87	3.97	4.07	4.18	4.28	4.38	4.48	4.59	4.69
34°F	1.68	1.78	1.86	1.97	2.06	2.18	2.28	2.38	2.48	2.58	2.69	2.79	2.90	3.00	3.09	3.19	3.29	3.39	3.49	3.59	3.69	3.79	3.90	4.00	4.10	4.20	4.30	4.40	4.50	4.60
35°F	1.63	1.73	1.83	1.93	2.02	2.14	2.24	2.34	2.43	2.52	2.63	2.73	2.83	2.93	3.02	3.12	3.22	3.32	3.42	3.52	3.62	3.72	3.82	3.92	4.01	4.11	4.21	4.31	4.41	4.51
36°F	1.60	1.69	1.79	1.88	1.98	2.09	2.19	2.29	2.38	2.47	2.57	2.67	2.77	2.86	2.96	3.05	3.15	3.24	3.34	3.43	3.53	3.63	3.72	3.82	3.92	4.01	4.11	4.21	4.30	4.40
37°F	1.55	1.65	1.74	1.84	1.94	2.04	2.14	2.24	2.33	2.42	2.52	2.62	2.71	2.80	2.90	3.00	3.09	3.18	3.27	3.37	3.46	3.56	3.65	3.75	3.84	3.94	4.03	4.13	4.22	4.32
38°F	1.52	1.61	1.71	1.80	1.90	2.00	2.10	2.20	2.29	2.38	2.48	2.57	2.66	2.75	2.85	2.94	3.03	3.12	3.21	3.30	3.40	3.49	3.59	3.68	3.77	3.87	3.96	4.06	4.15	4.24
39°F	1.49	1.58	1.67	1.77	1.86	1.96	2.06	2.15	2.25	2.34	2.43	2.52	2.61	2.70	2.80	2.89	2.98	3.07	3.16	3.25	3.34	3.44	3.53	3.62	3.71	3.81	3.90	3.99	4.08	4.18
40°F	1.47	1.56	1.65	1.74	1.83	1.92	2.01	2.10	2.20	2.30	2.39	2.47	2.56	2.65	2.75	2.84	2.93	3.01	3.10	3.19	3.28	3.37	3.46	3.55	3.64	3.73	3.82	3.91	4.01	4.10
41°F	1.43	1.52	1.61	1.70	1.79	1.88	1.97	2.06	2.16	2.25	2.34	2.43	2.52	2.60	2.70	2.79	2.88	2.96	3.05	3.14	3.23	3.32	3.41	3.50	3.59	3.68	3.77	3.86	3.95	4.04
42°F	1.39	1.48	1.57	1.66	1.75	1.85	1.94	2.02	2.12	2.21	2.30	2.39	2.48	2.56	2.65	2.74	2.83	2.91	3.00	3.09	3.18	3.26	3.35	3.44	3.53	3.62	3.70	3.79	3.88	3.97
43°F	1.37	1.46	1.54	1.63	1.72	1.81	1.90	1.99	2.08	2.17	2.26	2.34	2.43	2.52	2.61	2.69	2.78	2.86	2.95	3.04	3.13	3.21	3.30	3.39	3.47	3.56	3.65	3.74	3.82	3.91
44°F	1.35	1.43	1.52	1.60	1.69	1.78	1.87	1.95	2.04	2.13	2.22	2.30	2.39	2.47	2.56	2.64	2.73	2.81	2.90	2.99	3.07	3.10	3.24	3.33	3.41	3.50	3.58	3.67	3.76	3.84
45°F	1.32	1.41	1.49	1.58	1.66	1.75	1.84	1.91	2.00	2.08	2.17	2.26	2.34	2.42	2.51	2.60	2.69	2.77	2.86	2.94	3.02	3.11	3.19	3.28	3.36	3.45	3.53	3.62	3.70	3.79
46°F	1.28	1.37	1.45	1.54	1.62	1.71	1.80	1.88	1.96	2.04	2.13	2.22	2.30	2.38	2.47	2.55	2.64	2.72	2.81	2.89	2.98	3.06	3.15	3.23	3.31	3.40	3.48	3.57	3.65	3.74
47°F	1.26	1.34	1.42	1.51	1.59	1.68	1.76	1.84	1.92	2.00	2.09	2.18	2.26	2.34	2.42	2.50	2.59	2.67	2.76	2.84	2.93	3.02	3.09	3.18	3.26	3.35	3.43	3.51	3.60	3.68
48°F	1.23	1.31	1.39	1.48	1.56	1.65	1.73	1.81	1.89	1.96	2.05	2.14	2.22	2.30	2.38	2.46	2.54	2.62	2.71	2.79	2.88	2.96	3.04	3.13	3.21	3.30	3.38	3.46	3.54	3.63
49°F	1.21	1.29	1.37	1.45	1.53	1.62	1.70	1.79	1.86	1.93	2.01	2.10	2.18	2.25	2.34	2.42	2.50	2.58	2.67	2.75	2.83	2.91	3.00	3.07	3.15	3.23	3.31	3.39	3.47	3.56
50°F	1.18	1.26	1.34	1.42	1.50	1.59	1.66	1.74	1.82	1.90	1.98	2.06	2.14	2.21	2.30	2.38	2.46	2.54	2.62	2.70	2.78	2.86	2.94	3.02	3.10	3.17	3.25	3.33	3.41	3.49
51°F	1.18	1.26	1.34	1.42	1.49	1.57	1.64	1.71	1.79	1.87	1.95	2.02	2.10	2.18	2.26	2.34	2.42	2.49	2.57	2.65	2.74	2.82	2.90	2.97	3.05	3.13	3.19	3.27	3.34	3.42
52°F	1.16	1.23	1.31	1.39	1.46	1.54	1.61	1.68	1.76	1.84	1.92	1.99	2.06	2.14	2.22	2.30	2.38	2.45	2.53	2.61	2.68	2.76	2.84	2.92	3.00	3.06	3.13	3.22	3.30	3.37
53°F	1.14	1.21	1.29	1.36	1.44	1.51	1.59	1.66	1.74	1.81	1.89	1.96	2.03	2.10	2.18	2.26	2.34	2.41	2.49	2.57	2.64	2.71	2.79	2.86	2.94	3.01	3.09	3.16	3.24	3.31
54°F	1.12	1.19	1.27	1.34	1.41	1.49	1.56	1.63	1.71	1.78	1.86	1.93	2.00	2.07	2.15	2.22	2.30	2.37	2.45	2.52	2.59	2.66	2.74	2.81	2.89	2.96	3.04	3.10	3.17	3.24
55°F	1.10	1.17	1.24	1.31	1.39	1.46	1.53	1.60	1.68	1.75	1.82	1.89	1.97	2.04	2.12	2.18	2.26	2.33	2.40	2.47	2.54	2.62	2.69	2.76	2.83	2.89	2.97	3.04	3.11	3.18
56°F	1.07	1.15	1.22	1.29	1.36	1.43	1.50	1.57	1.65	1.72	1.79	1.86	1.93	2.00	2.08	2.15	2.22	2.29	2.36	2.43	2.50	2.57	2.64	2.71	2.78	2.85	2.92	2.99	3.06	3.13
57°F	1.05	1.12	1.19	1.26	1.33	1.40	1.47	1.54	1.62	1.70	1.77	1.83	1.90	1.97	2.04	2.11	2.18	2.25	2.32	2.39	2.46	2.53	2.60	2.66	2.73	2.80	2.87	2.94	3.00	3.08
58°F	1.03	1.10	1.17	1.24	1.30	1.37	1.44	1.51	1.59	1.67	1.74	1.80	1.87	1.94	2.01	2.08	2.15	2.23	2.28	2.35	2.42	2.48	2.55	2.62	2.69	2.75	2.82	2.88	2.95	3.02
59°F	1.02	1.09	1.16	1.22	1.29	1.36	1.43	1.49	1.56	1.64	1.71	1.77	1.84	1.91	1.98	2.04	2.11	2.17	2.24	2.31	2.38	2.43	2.50	2.57	2.64	2.70	2.77	2.84	2.91	2.97
60°F	1.01	1.08	1.15	1.21	1.28	1.34	1.41	1.47	1.54	1.62	1.62	1.75	1.82	1.88	1.95	2.01	2.08	2.14	2.21	2.27	2.34	2.40	2.47	2.53	2.60	2.66	2.73	2.79	2.86	2.92
61°F	0.99	1.05	1.12	1.18	1.24	1.31	1.37	1.44	1.50	1.57	1.63	1.69	1.76	1.82	1.89	1.95	2.02	2.08	2.14	2.21	2.27	2.34	2.40	2.47	2.53	2.59	2.66	2.72	2.79	2.85
62°F	0.96	1.02	1.09	1.15	1.21	1.27	1.34	1.40	1.46	1.52	1.59	1.65	1.71	1.78	1.84	1.90	1.97	2.03	2.09	2.15	2.22	2.28	2.34	2.41	2.47	2.53	2.59	2.66	2.72	2.78
63°F	0.93	0.99	1.06	1.12	1.18	1.24	1.30	1.36	1.42	1.49	1.55	1.61	1.67	1.73	1.79	1.85	1.92	1.98	2.04	2.10	2.16	2.22	2.28	2.35	2.41	2.47	2.53	2.59	2.65	2.71
64°F	0.91	0.97	1.03	1.09	1.15	1.21	1.27	1.33	1.39	1.45	1.51	1.57	1.63	1.69	1.75	1.81	1.87	1.93	1.99	2.05	2.11	2.17	2.23	2.29	2.35	2.41	2.47	2.52	2.58	2.64
65°F	0.88	0.94	1.00	1.06	1.11	1.17	1.23	1.29	1.35	1.41	1.46	1.52	1.58	1.64	1.70	1.76	1.82	1.87	1.93	1.99	2.05	2.11	2.17	2.23	2.28	2.34	2.40	2.46	2.52	2.58

Temperature

Table Key:

- Blue = Under-Carbonated, 0-1.49 volumes CO2
- Gray = Stouts and porters, 1.50-2.19 volumes CO2
- Green = Lagers, Ales, Ambers, most beers, 2.20-2.59 volumes CO2
- Yellow = Highly carbonated ales, Lambics, Wheat beers 2.60-4.0 volumes CO2
- Red = Over-carbonated (except for certain specialty ales) 4.01+ volumes CO2

Blichmann Engineering Product Warranty

A. Limited Warranty

1. Blichmann Engineering warrants to the original purchaser that this product will be free from manufacturing defects in material and workmanship for a period of one (1) year from the date of purchase by the customer. Proof of purchase is required. Blichmann Engineering's obligation to repair or replace defective materials or workmanship is the sole obligation of Blichmann Engineering under this limited warranty.
2. This product is for home use only. The limited warranty covers only those defects that arise as a result of normal use of the product and does not cover any other problems, including, but not limited to, those that arise as a result of:
 - a. Improper maintenance or modification;
 - b. Damage due to incorrect voltage or improper wiring by customer;
 - c. Operation outside of the product's specifications;
 - d. Carelessness or neglect to operate the product in accordance with instructions provided with the product;
 - e. Damaging the tamper label on the product;
 - f. Damage by over-tightening the fasteners;
 - g. Failure to follow cleaning and / or maintenance procedures; or
 - h. Exceeding published operational temperatures.
3. Blichmann Engineering reserves the right to request delivery of the defective component for inspection before processing the warranty claim. If Blichmann Engineering receives, during the applicable warranty period, notice of a defect in any component that is covered by the warranty, Blichmann Engineering shall either repair or replace the defective component with a new or rebuilt component at Blichmann Engineering's option.
4. Blichmann Engineering must be notified within seven (7) days of the delivery date of any shipping damage. Customer is responsible for shipping damage outside of this time period. Approval for return must be provided by Blichmann Engineering prior to any return. Customer is responsible for keeping all original packaging material for warranty returns. Blichmann Engineering is not responsible for damage from improperly packaged warranty returns, and these repair costs will be the sole responsibility of the customer. Shipping costs for warrantee returns are covered only for the contiguous United States.
5. Blichmann Engineering's limited warranty is valid in any country where the product is distributed.

B. Limitations of Warranty

1. Any implied warranty that is found to arise by way of state or federal law, including any implied warranty of merchantability or any implied warranty of fitness, is limited in duration to the terms of this limited warranty and is limited in scope of coverage to this warranty. Blichmann Engineering disclaims any express or implied warranty, including any implied warranty of fitness for a particular purpose or merchantability, on items excluded from coverage as set forth in this limited warranty.
2. Blichmann Engineering makes no warranty of any nature beyond that contained in this limited warranty. No one has authority to enlarge, amend, or modify this limited warranty, and Blichmann Engineering does not authorize anyone to create any other obligation for it regarding this product.
3. Blichmann Engineering is not responsible for any representation, promise, or warranty made by any independent dealer or other person beyond what is expressly stated in this limited warranty. Any selling or servicing dealer is not Blichmann Engineering's agent, but an independent entity.

C. Limitations of Liability

1. The remedies provided in this warranty are the customer's sole and exclusive remedies.
2. Except for the obligations specifically set forth in this warranty, in no event shall Blichmann Engineering be liable for direct, indirect, special, incidental, or consequential damages, whether based on contract, tort, or any other legal theory and whether or not advised of the possibility of such damages.
3. This warranty does not cover, and in no event shall Blichmann Engineering be liable for, travel, lodging, or any other expense incurred due to manufacturing defects in material and workmanship, or any other reason.
4. Any performance of repairs after the warranty coverage period has expired or performance of repairs regarding anything excluded from coverage after this limited warranty shall be considered good-will repairs and they will not alter the terms of this limited warranty, or extend any warranty coverage period.
5. Venue for any legal proceedings relating to or arising out of this warranty shall be in Tippecanoe County, Indiana, United States, which courts will have exclusive jurisdiction.

D. Local Law

1. This warranty gives the customer specific legal rights. The customer may also have other rights that